

1 Download & Install Software

- Go to www.bushnellgolfgps.com. Make sure you have the latest version of **Java** (link provided).
- Click **Download and Install Software** and **Save** the file (zip folder) to your desktop. You will automatically receive the correct file for your computer OS.
- "Unzip" the downloaded file and open the folder inside. Run the **Bushnell_Neo_Installer.exe**
- Select "**USB Driver Setup**" to install the required driver.
- Select "**Sync Application**" to install the Sync software.

DOWNLOAD

INSTALL

JAVA

Sync App

Driver and Sync App

*Free software to decompress zip files is available on the internet if it was not included with your PC or Mac.

2 Charge & Connect Neo to PC

- Charge the Neo for at least 6 hours via supplied AC adapter & USB cable.
- Connect the cable to a USB port on your computer.
- Insert other end of the cable into the USB port on the Neo.
- Hold the **Power** button for approximately 2 seconds.
- A "USB Mode" message will appear on the Neo's display when it is ready to accept data.



3 Join iGolf.com & Download Course Data

- Launch the Bushnell Neo Sync app from the desktop icon, and click the "**GPS Download**" tab. Fill in the "**Join Now**" info to setup an iGolf membership (if already a member, just "Log In").
- Once logged in, select 'GPS Courses' from the header menu, enter the name of a golf course in the search bar and click the 'Search' button.
- Select the desired course from the results list to access the course download page, then click 'Download GPS & Scorecard'.
- After downloading, the course name will appear in the "My Courses" section in the left column of the sync application.

4 Transfer Course Data to Neo

- Select and highlight the course(s) you want to load onto the Neo from the "My Courses" section in the left column of the Sync application.
- Select the "Send" button to transfer the course(s) to the Neo.
- Once the course data transfer is complete, disconnect the USB cable from the Neo.



5 Play Golf!

- Hold down the **Power** button for approximately 2 seconds.
- Move away from tall buildings and trees for unobstructed reception of GPS satellites. Wait for a GPS signal to be acquired. *The initial GPS satellites signal lock can take up to 5 minutes.*
- Highlight "Play Golf" and press the "OK/SHOT" button.
- Locate the course you are playing and press "OK/SHOT".
- The display shows distances to the Center, Front (F) and Back (B).
- Use the **Up/Down Arrow** buttons to change holes.
- Press the **SCREEN** button to view "custom points" for a hole.
- Press the **ESC/MENU** button to access other features.



Power SCREEN Up/Down OK/SHOT ESC/MENU

The complete Owner's Manual and other support resources for the Neo are available online at:

<http://www.bushnellgolf.com>

Select "GPS Rangefinders", then "Neo", or click on "Customer Support"

Bushnell